

**P/N#UHK15**

## **Roto-Shear Universal Hose Kit Assembly Instructions**

### **Kit Includes:**

**2 of a 27000-47 ROTSHR HYD ½" SS BALL VALVE C/W LOCK**

**4 of a 27000-46 HYD FTG 8MPL-10MJT**

**4 of a 27000-45 HOSEHYD#8/2WIR/120"/10MB/10FJX**

### **Assembly:**

When complete will consist of 2 identical assemblies:

1. Using a good quality hydraulic pipe thread fitting sealant apply to the male pipe thread portion of the leg of the tee fitting (p/n#27000-46).
2. Install the tee fitting (p/n#27000-46) in both ends of the ball valve (p/n#27000-47).
3. Install the #10FJX (Female JIC Swivel) end of the hoses (p/n#27000-45) to the tee fitting (p/n#27000-46) as shown so that both hoses (p/n#27000-45) are on different tee fittings (p/n#27000-47), but on the same side of the valve (p/n#27000-47).
4. Each hose assembly is now ready for installation on a side of the header.

