
CROP DIVIDER

INSTALLATION MANUAL

JD SPRAYER MOUNT R4044

FREEFORM PLASTICS

BOX 159, ST. BRIEUX, SK CANADA

S0K 3V0

P: 1-306-275-2155

F: 1-306-275-2101

EMAIL: SALES@FREEFORMPLASTICS.COM

WEB SITE: WWW.FREEFORMPLASTICS.COM

NOTES

- LOCTITE ALL FASTENERS THAT ARE NOT SELF LOCKING
- ONLY RIGHT SIDE SHOWN

TOOLS REQUIRED

- RED LOCTITE
- WRENCH AND SOCKET

INSTALLATION INSTRUCTIONS

1. FASTEN MOUNT TO SPRAYER
 - REMOVE CURRENT FASTENERS USED FOR THE FENDER MOUNTS.
 - FASTEN DIVIDER MOUNT WELDMENT TO AXLE USING THE FOLLOWING FASTENERS:

○ 1088-46	BOLT M16 X 100 GR8.8	QTY 3
○ 1325-33	WSHR 5\8 SAE PLD	QTY 3
○ 5080-32-1.750	DOM 1-1/2ODX1.02 C1018/C1020	QTY 3
 - TORQUE TO MACHINE SPECIFICATIONS.



2. REPEAT FOR LEFT SIDE ASSEMBLY

Diagram showing two views of a JD Mount Pair R4044. The top view shows a side profile with callouts 4 and 5. The bottom view shows a top-down perspective with callouts 1, 2, and 3.

TOLERANCES UNLESS OTHERWISE SPECIFIED: ANGLES ± 1° FRACTIONS ± 1/16" DECIMALS .XX ± .01 .XXX ± .005	REV	DATE	DESCRIPTION	NCB	DKH	BY	CB
	0	13-Jan-22	COMPLETED DRAWING				
THE INFORMATION CONTAINED IN THIS DOCUMENT IS THE SOLE PROPERTY OF SOUTHCAL INDUSTRIES LTD. USE SHALL BE LIMITED TO THE PURPOSES FOR WHICH THE INFORMATION HAS BEEN PROVIDED. ANY REPRODUCTION OR DISCLOSURE TO THIRD PARTIES, IN WHOLE OR PART, WITHOUT THE WRITTEN PERMISSION OF SOUTHCAL INDUSTRIES LTD. IS PROHIBITED.							
ITEM # PART # DESCRIPTION QTY.							
1 1088-46 BOLT M16 X 100 GR8.8 6							
2 1325-33 WSHR 5/8 SAE PLD 6							
3 5080-32-1.750 DOM 1-1/2ODX1.02 C1018/C1020 6							
4 26008-42-01 JD RH DIVIDER MT 1							
5 26008-42-02 JD LH DIVIDER MT 1							
6 26008-42-99 MANUAL SPRAYER JD 26008-42 1							
FREEFORM PLASTICS ST. BRIEUX, SASKATCHEWAN CANADA S9W 3V0							
JD MOUNT PAIR R4044							
DATE 13-JAN-22				DRN BY	DKH	SCALE 1:8	SIZE A
DOCUMENT NO. 26008-42				WEIGHT 64.6 LB		PAGE 1 OF 1	
				COLOR		NONE	